


BRIO 500

Setup Guide
设置指南




CONTENTS


English	3	简体中文	11
-------------------	---	----------------	----

KNOW YOUR PRODUCT

BRIO 500 FRONT VIEW WITH FUNCTION INDICATIONS




MOUNT DESIGN OVERVIEW



STEP 1: WHAT'S IN THE BOX


1. Webcam with attached USB-C cable
2. Mount clip with removable mount adaptor
3. User documentation




STEP 2: DETERMINE MOUNT PLACEMENT

Placement to allow one-handed camera adjustments (using micro-suction pad)


1. Determine the best placement for your webcam before continuing.
2. Wipe the back of your monitor to clear any dust or dirt.



3. Remove the protective film from the micro-suction pad.



4. Open the mount fully and place on top of your monitor, being sure that the pad of the front clip makes contact with the front of the monitor.
5. Rotate the rear foot down until it makes contact with the back of the monitor.
6. Press the micro-suction pad to the back of your monitor firmly to create a good bond.




Note:

- The mount adaptor can be removed and reused for mounting adjustments without leaving residue.
- To clean the micro-suction pad, rinse with water to remove debris, and let it air dry in order to regain strong suction.


(Optional) Placement without the micro-suction pad

Slide the removable mount adapter down to remove it from the webcam foot. Adjust the foot on the mounting clip until it is flush with the back of your device and press firmly in place.




STEP 3: MOUNT ADAPTOR REMOVAL AND CLEANING

1. Remove the webcam from mount and gently peel the adaptor from one corner to remove.




2. With a wet finger gently rub the pad clear of dust and dirt and let the micro-suction pad air dry completely before remounting (do not use cloth or tissue to dry).
3. Repeat the monitor placement setup steps to best deploy your webcam.




STEP 4: ATTACH CAMERA TO THE MOUNT

Place the webcam into the magnet attachment point on top of the mount. Listen for an audible click indicating the webcam is properly seated on the mount.




STEP 5: CONNECT THE WEBCAM VIA USB-C & GET STARTED


1. Plug the USB-C connector into the USB-C port on your computer, monitor, laptop, or docking station.



2. Rotate the dial on the right side of the webcam to open/close the privacy shutter.



3. Adjust the webcam by turning side to side and tilting up and down to find the best framing for your video meetings.



STEP 6: SUCCESSFUL CONNECTION

LED activity light will light up when the webcam is in use by any video application.

LED activity lights:

- Video ON/Audio ON: White
- Video ON/Audio OFF: White
- Video OFF/Audio ON: Yellow
- Video OFF/Audio OFF: No light
- Firmware Update: Breathing Lilac




STEP 7: SHOW MODE

Easily show physical items in video calls by tilting the camera down to present sketches, objects, and work in progress. There are two ways to use Show Mode:


1. **If mount is secured with micro-suction**

pad: Using one hand, tilt the camera down to show your desktop, and tilt back up to show yourself.



2. **If mount is not secured with micro-suction**

pad: Hold the mount still with one hand and tilt the camera up or down with the other.



STEP 8: LOGI TUNE

Logi Tune helps boost your webcam performance with periodic software and firmware updates.


It is recommended to update your webcam. To do so, download Logi Tune from www.logitech.com/tune



www.logitech.com/tune

ADJUSTABLE OPTIONS


- Show Mode
- Auto-framing
- Zoom adjustment
- Field of View (90°/78°/65°)
- Image adjustment
- Auto-focus
- Disable mics
- LED on/off for video and audio




STEP 9: (OPTIONAL) ATTACH TO A TRIPOD

For placement on a tripod (not included)


1. Rotate counterclockwise to remove the mounting screw from the bottom of the webcam.



2. Locate the 1/4 inch tripod thread on the bottom of the universal mounting clip.



3. Secure the webcam on your tripod by twisting it into the 1/4 inch thread.
4. Repeat the monitor placement setup steps to best deploy your webcam.
5. Please refer to step 5 and 6 to complete your webcam setup.



DIMENSIONS

WEBCAM:

Height x Width x Depth:

1.2 in (31.5 mm) x 4.3 in (110 mm) x 1.2 in (31.5 mm)

Height x Width x Depth (incl. mount clip):

2 in (51.5 mm) x 4.3 in (110 mm) x 1.8 in (45 mm)

Weight: 4.2 oz (121 g), incl. mount clip & cable

Attached Cable length: 5 ft (1.5 m)

MOUNTING CLIP:

Height x Width x Depth:


1 in (25 mm) x 1.8 in (45.8 mm) x 2.6 in (65.1 mm)

Weight: 1.4 oz (40 g), incl. Removable mount adapter


www.logitech.com/support/Brio500

了解您的产品

BRIO 500 前视图，带功能指示




安装配件设计概览



步骤 1：包装内容


1. 带 USB-C 线缆的网络摄像头
2. 带可拆卸安装适配器的安装夹
3. 用户文档




步骤 2：确定安装位置

单手调节摄像头位置（使用微型吸盘）


1. 在继续之前确定网络摄像头的理想位置。
2. 擦拭显示器背面以清除灰尘或污垢。



3. 取下微型吸盘的保护膜。



4. 完全打开支架并将其放在显示器顶部，确保前夹板的衬垫与显示器的正面接触。
5. 向下旋转后支脚，直至接触到显示器的后部。
6. 将微型吸盘牢固地按在显示器背面，以形成良好的粘合。




注意：

- 安装适配器可以移除并重新用于安装调整，而不会留下任何残留物。
- 清洁微型吸盘时，请先用水冲洗掉碎屑，然后自然风干以恢复强大的吸力。


(可选) 不使用微型吸盘放置

向下滑动可拆卸安装适配器，将其从网络摄像头脚上卸下。调整安装夹上的支脚，直至与设备背面齐平，然后用力按压到位。




步骤 3：安装适配器的拆卸和清洁

1. 从安装配件上取下网络摄像头，轻轻地从一角剥下适配器以将其取下。




2. 用沾湿的手指轻轻擦去灰尘和污垢，让微型吸盘完全风干，然后再重新安装（不要使用布或纸巾擦干）。
3. 重复显示器放置设置步骤，以更好地部署网络摄像头。




步骤 4：将摄像头安装到安装配件上

将网络摄像头放入安装配件顶部的磁铁连接点。听到咔嗒声，表示网络摄像头已正确安装在支架上。




步骤 5：通过 USB-C 连接网络摄像头并开始使用


- 1. 将 USB-C 接头插入电脑、显示器、笔记本电脑或扩展坞的 USB-C 端口。



- 2. 旋转网络摄像头右侧的旋钮以打开/关闭隐私镜头盖。








- 3. 通过左右转动和上下倾斜来调整网络摄像头，找到适合视频会议的取景画面。



步骤 6：成功连接

当任何视频应用程序使用网络摄像头时，LED 活动指示灯都将点亮。


LED 活动指示灯：

- 视频开启/音频开启：白色 
- 视频开启/音频关闭：白色 
- 视频关闭/音频开启：黄色 
- 视频关闭/音频关闭：无指示灯 
- 固件更新：紫色呼吸灯 


步骤 7：显示模式

可向下倾斜摄像头以拍摄手绘、拍摄对象和进行中的工作，轻松将实体内容展示在视频通话之中。有两种使用显示模式的方法：

1. 如果支架是用微型吸盘固定的：用一只手向下倾斜摄像头即可拍摄桌面，向后倾斜即可拍摄您自己。



2. 如果支架没有用微型吸盘固定：一手握住支架，另一只手向上或向下倾斜摄像头。



步骤 8: LOGI TUNE

Logi Tune 通过定期的软件和固件更新帮助改善网络摄像头性能。


建议您及时更新网络摄像头。为此，请下载 Logi Tune：www.logitech.com/tune



www.logitech.com/tune

可调节选项


- 显示模式
- 自动取景
- 变焦调节
- 视野 (90°/78°/65°)
- 画面调节
- 自动对焦
- 禁用麦克风
- 视频和音频 LED 开/关




步骤 9: (可选) 连接三脚架

放置于三脚架上 (需另购)


1. 逆时针旋转，卸下网络摄像头底部的安装螺丝。



2. 找到通用安装夹底部的 1/4 英寸三脚架安装螺纹。



3. 将三脚架拧入 1/4 英寸安装螺纹，将网络摄像头固定于三脚架上。
4. 重复显示器放置设置步骤，以更好地部署网络摄像头。
5. 请参阅步骤 5 和 6 完成网络摄像头设置。



尺寸

网络摄像头：

高 x 宽 x 深：

约 31.5 毫米 x 约 110 毫米 x 约 31.5 毫米

高 x 宽 x 深（含安装夹）：

约 51.5 毫米 x 约 110 毫米 x 约 45 毫米

重量：约 121 克，含安装夹和线缆

随附线缆长度：约 1.5 米

安装夹：

高 x 宽 x 深：

约 25 毫米 x 约 45.8 毫米 x 约 65.1 毫米

重量：约 40 克，含可拆卸安装适配器

www.logitech.com/support/Brio500

版权所有 © 2022 罗技。罗技、Logi、Logitech 和罗技标志为罗技欧洲公司和/或其美国及其他国家/地区附属公司的商标，并或已注册。蓝牙™ 文字商标和标志为 Bluetooth SIG, Inc. 所有的注册商标。罗技对此类商标和标志的所有使用均已获得授权。USB-C 是 USB Implementers Forum 的注册商标。所有其他商标均是其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。

本文内所适用的数据如无特别说明均来自罗技有限公司和/或其关联公司和/或其指定的供应商。

WEB-621-002252 002