





Logitech® Wireless Mouse M560  
罗技® 无线鼠标 M560


Setup Guide  
设置指南




1







2



3



[www.logitech.com/downloads](http://www.logitech.com/downloads)



### English

#### Mouse features

#### Windows® 8 features

##### 1. Windows 8 edge menu button:

- Hold down the button and move your mouse to the **left** to display the Windows 8 **App bar**. Release to select.
- Hold down the button and move your mouse to the **right** to display the Windows 8 **Charms**. Release to select.

##### 2. Scroll wheel:

- Press the wheel down to switch between hyper-fast scrolling and click-to-click scrolling.
- Tilt the wheel left/right for Internet back/forward.

##### 3. Show the Windows desktop.

##### 4. Show the Windows 8 Start screen.

For more Windows 8 mouse features and options, download the latest software from [www.logitech.com/downloads](http://www.logitech.com/downloads).

#### Windows 7 features (software required)

##### 1. Application switcher.

##### 2. Scroll wheel:

- Press the wheel down to switch between hyper-fast scrolling and click-to-click scrolling.
- Tilt the wheel left/right for horizontal scroll.

##### 3. Back button.

##### 4. Forward button.

To activate the Windows 7 features you must download the latest software from [www.logitech.com/downloads](http://www.logitech.com/downloads).

##### 5. Battery LED. Illuminates red when battery power is low, green when battery power is good.

##### 6. On/Off slider switch.

##### 7. Receiver storage.

##### 8. Battery door.

### 简体中文

#### 鼠标功能

#### Windows® 8 功能

##### 1. Windows 8 侧边菜单按钮:

- 按住按钮并向左移动鼠标可显示 Windows 8 应用程序栏。释放按钮后可进行选择操作。
- 按住按钮并向右移动鼠标可显示 Windows 8 Charms。释放按钮后可进行选择操作。

##### 2. 滚轮:

- 按下滚轮可在超快滚动和逐击滚动模式之间进行切换。
- 向左/右倾斜滚轮可使网页后退/前进。

##### 3. 显示 Windows 桌面。

##### 4. 显示 Windows 8 开始屏幕。

如欲了解鼠标更多的 Windows 8 功能和选项, 请登录 [www.logitech.com/downloads](http://www.logitech.com/downloads) 下载最新软件。

#### Windows 7 功能 (需安装软件)

##### 1. 切换应用程序。

##### 2. 滚轮:

- 按下滚轮可在超快滚动和逐击滚动模式之间进行切换。
- 向左/右倾斜滚轮可实现横向滚动。

##### 3. 后退按钮。

##### 4. 前进按钮。

如要激活 Windows 7 功能, 必须从 [www.logitech.com/downloads](http://www.logitech.com/downloads) 下载最新软件。

##### 5. 电池 LED 指示灯。电池电量低时亮起红灯, 电池电量充足时亮起绿灯。

##### 6. 开启/关闭滑动开关。

##### 7. 接收器收存。

##### 8. 电池盖。



### English

Logitech® Unifying technology connects up to six compatible Logitech mice and keyboards to the same receiver, using only one USB port for multiple devices. To learn more, visit [www.logitech.com/unifying](http://www.logitech.com/unifying).

### 简体中文

罗技® Unifying 技术可将多达六个兼容的罗技鼠标和键盘连接至相同接收器，只需一个 USB 端口就可连接多个设备。如欲了解更多信息，请访问 [www.logitech.com/unifying](http://www.logitech.com/unifying)。

### English

#### Troubleshooting

#### Mouse is not working?

- Restart the mouse by turning it off and then back on?
- If the battery LED illuminates red, replace the battery.
- Check that the Unifying receiver is properly connected to a USB port.
- If the Unifying receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
- Try a different surface. Remove metallic objects between the mouse and the Unifying receiver.
- Keep the Unifying receiver as far as possible from other USB 3.0 devices, by plugging it on a USB port the opposite side of the computer from the USB 3.0 device, or by using a shielded USB-extender cable.
- A shielded USB-extender cable is available for Logitech customers experiencing connection problems at [www.logitech.com/usbextender](http://www.logitech.com/usbextender).

### 简体中文

#### 疑难解答

#### 鼠标不工作？

- 关闭并重启鼠标。
- 如果电池 LED 指示灯亮起红灯，请更换电池。
- 检查 Unifying 接收器是否正确地插入 USB 端口。
- 如果 Unifying 接收器插入的是 USB 集线器，请尝试将其直接插入电脑的 USB 端口。
- 尝试其他表面。移除鼠标和 Unifying 接收器之间的金属物体。
- 使 Unifying 接收器尽量远离其他 USB 3.0 装置，可将其插入电脑上位于 USB 3.0 装置相反一侧的 USB 端口，或使用屏蔽性良好的 USB 延长线。
- 遇有连接问题的罗技客户，可通过 [www.logitech.com/usbextender](http://www.logitech.com/usbextender) 获得屏蔽性良好的 USB 延长线。

### Table of Toxic and Hazardous Substances/Elements and their Content

#### 产品中有毒有害物质或元素的名称及含量 根据中国<<电子信息产品污染控制管理办法>>

Control Device 鼠标						
有毒有害物质或元素						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电缆 Cable	X	○	○	○	○	○
电路板组件 PWAs	X	○	○	○	○	○
塑料外壳 Plastic enclosure	○	○	○	○	○	○
塑料部件 Plastic parts	○	○	○	○	○	○
金属部件 Metal parts	X	○	○	○	○	○

○ = 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。

X = 表示该有毒有害物质至少在该部件的某一均质的含量超出 SJ/T11363-2006 标准规定的限量要求。

表中标有“X”的所有部件都符合欧盟 RoHS 法规

“欧洲议会和欧盟理事会 2003 年 1 月 27 日关于电子电器设备中限制使用某些有害物质的 2002/95/EC 号指令”

注：环保使用期限的参考标取决于产品正常工作的温度和湿度等条件